




akustikmiljö

BETTER LOOKING SOUND

S

GB




Stolstass



Chair pad

Innehåll

Content



Stolstass
Chair pad



- Tryck på gummitassen på benet.
- Simply fit the rubber chair pad onto the chair leg.