


PRINT fototavla/ picture

AKUSTIKMILJÖ // MILJÖVÄNLIGA LJUDABSORBENTER MED FOKUS PÅ FUNKTION & DESIGN



Rengöring

Rengör produktens textila ytor regelbundet. Enklast med torrborstning, avblåsning med tryckluft eller dammsugning. Våtrengör hårda ytor med kallt vatten och mild rengöringsmedel.

Återvinning

Produkten kan demonteras och återanvändas någon annanstans. Spillet från tillverkningen går tillbaka till produktionen av kärnmaterialet. Förbrukad produkt kan återvinnas genom att sortera ramen som metall samt förbränning av kärnmaterialet. Produkten förpackas i wellpapp som skall återvinnas efter leverans.

Material

PRINT tillverkas av EcoSUND samt en yta av textil, samt en ram av metall.

Maintenance

Clean the product's textile surfaces regularly. Easiest with dry brushing, compressed air or vacuuming. Clean hard surfaces with cold water and mild detergent.

Recycling

The product can be dismantled and reused elsewhere. The waste from the production returns to the manufacturing of the core material. Used product can be recycled by sorting the frame as metal and combustion of the core material. The product is packed in corrugated paper to be recycled after delivery.

Raw material

PRINT is produced of EcoSUND and is laminated with textile and a frame of metal.

